


Why	Cleaning dispensing and blender areas	
Time required	5 minutes to prepare	15 minutes to complete
Time of day	End of shift or end of day.	For 24-hour restaurants: End of shift.
Hazard icons		





Tools and supplies














Important Information – Before you start!

- Always wash your hands prior to starting the cleaning processes.
- Keep all supplies clean – Store in a clean and dedicated area.
- Wash / Sanitize all cleaning supplies prior to use.
- Do NOT use any of the cleaning supplies for any other purposes than Helix cleaning.
- Keep the spider away from the floor. Store inside a cleaning bucket or sanitized ice tray.

Procedure- Press Menu button: Then press Daily Sanitize button to begin

<p>Daily Clean Instructions: -Press PLAY to start the daily cleaning process.</p> <p>Clean and Sanitize all cleaning accessories before you begin.</p>		<p>2 Dispenser Area Cleaning and Sanitizing Step 2 of 16: -Scrub and sanitize hands. -Remove, scrub, rinse, and sanitize the center cup targeting tray at the three compartment sink. -Press PLAY to continue.</p>	
<p>1 Daily Cleaning Procedures Step 1 of 16: Supplies needed- Clean, sanitized soaked cloth -Qty 1 Spray Bottle with McDonalds approved Cleaner. -Qty 1 Spray Bottle with McDonalds approved Sanitizer. -Qty 2 Daily Clean Cups for Cleaning Agent. -Qty 2 Daily Clean Cups for Sanitizer.</p>		<p>3 Dispenser Area Cleaning Step 3 of 16: -Spray the dispenser area, dispenser nozzles and drain area with cleaning solution. -Wipe with a clean, sanitized soaked cloth. -Press PLAY to continue.</p>	

Daily Cleaning Process (continued)

<p>4 Dispenser Area Sanitizing Step 4 of 16: -Spray dispenser head thoroughly with sanitizer. -Allow to air dry. -Re-install the cup targeting tray. -Press PLAY to continue.</p>		<p>10 Blender Module Sanitization Step 10 of 16: -Spray sanitizer solution on blend shield, as well as fully saturate inside the top of the blend chamber. -Insert sanitized cloth and wipe clean. -Allow to air dry. -Press PLAY to continue.</p>	
<p>5 Blender Module Cleaning Step 5 of 16: -Place one cup filled with cleaning solution into each blender chamber. -Press PLAY to continue.</p>		<p>11 Blender Wash Basin Cleaning Step 11 of 16: -Spray the cup holders and the cup holder basins with cleaning solution and wipe clean with sanitizer soaked cloth. -Press PLAY to continue.</p>	
<p>6 Blender Module Rinsing Step 6 of 16: -Remove the cup from each chamber. -Press PLAY to continue.</p>		<p>12 Blender Wash Basin Sanitization Step 12 of 16: -Spray the cup holders and the cup holder basins with sanitizer solution. -Allow to air dry. -Re-install the cup holders into chamber. -Press PLAY to continue.</p>	
<p>7 Blender Module Cleaning - Clean Shield Step 7 of 16: -Press PLAY to move the shields to the HOME position.</p>		<p>13 Blender Module Sanitization Step 13 of 16: -Place one cup filled with sanitizer solution into each chamber. -Press PLAY to continue.</p>	
<p>8 Blender Module Cleaning Step 8 of 16: -Remove cup holders. -Spray cleaner inside the top of the blend chamber. Fully saturate the top of the chamber. - Insert brush and clean in circular motion the top of the chamber, and shield. Clean thoroughly. -Press PLAY to continue.</p>		<p>14 Blender Module Cleaning Step 14 of 16: -Remove cup from each chamber. -Press PLAY to continue.</p>	
<p>9 Blender Module Sanitization Step 9 of 16: -Press PLAY to move shields to the HOME position.</p>			

Daily Cleaning Process (continued)

15	Whip Cream Cradle Cleaning and Sanitizing Step 15 of 16: -Remove the whip cream plastic holder. -Scrub, rinse, and sanitize holder in 3 compartment sink. - Re-install holder. -Press PLAY to continue.	
16	Whip Cream Cradle Cleaning and Sanitizing Step 16 of 16: -Put cleaning supplies away. -Press PLAY to continue.	