

5 Wipe valves.


Wipe the inside of the diffuser area on each valve with a clean, sanitized towel.

Reinstall nozzles and

diffusers. Push each diffuser up into the valve. Reinstall the nozzles and gently twist them to the right (clockwise) to tighten them.







Sanitizer solution.

Chemicals Sanitizer solution

Remove diffusers.

Pull straight down on each

diffuser to remove it. Place

Clean the nozzles and

brush. Rinse them under

them. Air dry on a clean,

sanitized surface.

the diffusers in the bucket of McD Sanitizer solution.

2

3

- broken or missing parts.



IMI Cornelius Beverage Tower Model FFV